



Yacht Router - Mini

User Manual

version 1.2

CONTENTS

1.	COPYRIGHT NOTICE	3
2.	RoHS COMPLIANT	3
3.	INTRODUCING YACHT ROUTER SOLUTION	3
4.	DISCLAIMER	3
5.	WARNING	3
6.	SAFETY INSTRUCTIONS	3
7.	ABOUT YACHT ROUTER MINI	4
8.	FEATURES	4
9.	SPECIFICATIONS	5
9.1.	<i>Ethernet WAN input</i>	5
9.2.	<i>LAN</i>	5
9.3.	<i>WIFI</i>	5
9.4.	<i>Mobile network</i>	5
9.5.	<i>Expansions</i>	5
9.6.	<i>Power and Dimensions</i>	5
9.7.	<i>Operating environment range</i>	5
9.8.	<i>Dimensions</i>	5
10.	PACKAGING	5
11.	INSTALLATION INSTRUCTIONS	6
11.1.	<i>Connect WIFI and mobile network antennas</i>	6
11.2.	<i>Connect satellite systems (WAN) to Yacht Router</i>	8
11.3.	<i>Connect LAN equipment to Yacht Router</i>	8
11.4.	<i>Connect Touch Screen Controller or computer that will control Yacht Router</i>	9
11.5.	<i>Connect power supply to Yacht Router Mini</i>	9
12.	SETUP PROCEDURE	10
12.1.	<i>Install Yacht Router Control Software to your computer</i>	10
12.2.	<i>Using Touch Screen Controller with Yacht Router</i>	10
12.3.	<i>Power on Yacht Router</i>	10
12.4.	<i>Yacht Router initial setup</i>	10
12.5.	<i>Satellite Network setup</i>	11
12.6.	<i>Mobile Network setup</i>	12
12.7.	<i>WIFI Network setup</i>	13
12.8.	<i>Vessel LAN network setup</i>	14
12.9.	<i>Vessel WIFI 1 network setup</i>	14
12.10.	<i>Vessel WIFI 2 network setup</i>	14
13.	HOT TO USE YACHT ROUTER CONTROL SOFTWARE	15
13.1.	<i>Main Screen</i>	15
13.2.	<i>How to enable and disable vessels networks</i>	15
13.3.	<i>Hot to switch Internet sources</i>	15
13.4.	<i>How to use Yacht Router Remote Support</i>	16
13.5.	<i>How to lock Yacht Router</i>	16
14.	LOCOMARINE LIMITED FACTORY WARRANTY	17
15.	FCC INTERFERENCE STATEMENT	17
16.	DECLARATION OF CONFORMITY	17
17.	INDUSTRY CANADA NOTICE TO USERS	17

1. COPYRIGHT NOTICE

Locomarine d.o.o. reserves the rights to alter the products described in this manual at any time without prior notice. This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer. Information provided in this manual is intended to be accurate and reliable. However, Locomarine d.o.o. assumes no responsibility for use of this manual, nor for any infringements upon the rights of third parties, which may result from such use.

2. RoHS COMPLIANT

All models in the Yacht Router series comply with the Restriction of Hazardous Materials (RoHS) Directive. This means that all components used to build Yacht Router are RoHS compliant. The RoHS Directive bans the placing on the EU market of new electrical and electronic equipment containing more than agreed levels of lead, cadmium, mercury, hexavalent chromium, polybrominated biphenyl (PBB) and polybrominated diphenyl ether (PBDE) flame retardants.

3. INTRODUCING YACHT ROUTER SOLUTION

Yacht Router is a complete network infrastructure solution for yacht or boat of any size. Yacht Router devices will help you to easily install, setup and control Internet connection on your yacht. The most important part of Yacht Router solution is software that control complete system. It is designed by professionals specialized in yacht communication systems in collaborations with experienced yacht captains. The result is a system that is simple to operate, maintain and control. Underneath simple touch user interface, Yacht Router is a solution with industry level of reliability, performance and unprecedented level of security.

4. DISCLAIMER

The content of this manual are well prepared by Locomarine d.o.o.

While we try to improve our equipment at all time, Locomarine d.o.o. shall incur no liability based on content, updates or modification of the content, or the lack of contents in this manual.

5. WARNING

The equipment said in this manual must only be used to which it was designed.

Improper operation or installation may cause damages to the equipment or personal injury. Locomarine d.o.o. will not incur any liability of equipment damage or personal injury due to improper use or installation of the equipment. It is strongly recommended to read this manual and the following safety instructions before proceeding to installation or operation.

6. SAFETY INSTRUCTIONS

ELECTRICAL SHOCK HAZARD: Do not open enclosure of the equipment if you are not qualified to do it.

TURN OFF THE POWER IMMEDIATELY IF WATER LEAKS INTO THE EQUIPMENT OR OBJECT DROPS INTO THE EQUIPMENT: Continue operating the equipment could cause electrical shock or fire. Contact your nearest distributor or dealer for service.

DO NOT DISASSEMBLE THE EQUIPMENT OR MODIFY THE EQUIPMENT: Improper disassemble or modification could cause electrical shock, fire, or personal injury.

AVOID OPERATING THE EQUIPMENT WITH WET HANDS: Electrical shocks could be resulted if operating with wet hands.

USE PROPER FUSE: Damage to the equipment or fire could be resulted if using improper fuse.

TURN OFF THE POWER IMMEDIATELY IF THE EQUIPMENT IS EMITTING SMOKE OR FIRE: Continue operating the equipment could cause electrical shock or fire. Contact your nearest distributor or dealer for service.


DO NOT PLACE ANY LIQUID-FILLED CONTAINER ON TOP OF THE EQUIPMENT:

7. ABOUT YACHT ROUTER MINI

Yacht Router Mini is intended for installation on smaller boats and yachts with single satellite Internet source (VSAT, Inmarsat, Iridium etc). It is equipped with two WIFI modules, one to connect Yacht Router to WIFI Hotspot in marina and another to establish two Yacht WIFI Access Points (Owner, Guests). Yacht Router Mini is equipped with 3G modem for mobile network connection.

8. FEATURES

- 1x Ethernet WAN input port for satellite system (100 Mbps per port)
- 1x Vessel-to-Shore WIFI for connection to WIFI HotSpot in the marina (b/g/n)
- 1x Client-to-Vessel WIFI for yacht WIFI Access Points (b/g)
- 2x WIFI antenna connectors (1x Vessel-to-Shore, 1x Client-to-Vessel)
- 2x Yacht WIFI Access Points (Owner, Guest)
- 1x 3G modem (HSPA+) for mobile network connections (4G/LTE ready)
- 4x LAN ports (100 Mbps)
- 1x Touch Screen Controller port
- wide input range DC (9-18V) power supply
- wall mount aluminum enclosure



9. SPECIFICATIONS

9.1. Ethernet WAN input

Ports: 1

Data rates: 100 Mbps (per port)

9.2. LAN

Ports: 4

Data rates: 100 Mbps (per port)

9.3. WIFI

Vessel-to-Shore WIFI (connection to WIFI HotSpot in the marina)

Type: b/g/n high power (25.6dBm/360mW)

Data rates: up to 150 Mbps

Antenna connectors: 1

Client-to-Vessel WIFI (Yacht WIFI Access Points)

Type: b/g (20dBm/100mW)

Data rates: up to 54 Mbps

Antenna connectors: 1

Yacht Access Points: 2 (Owner, Guest)

9.4. Mobile network

Air interfaces: HSPA+, HSDPA, HSUPA, UMTS, EDGE, GPRS, GSM

Air Interface on request (not included in the price): 4G/LTE

Frequency bands: - WCDMA 850/1900/2100 MHz - EDGE/GPRS/GSM 850/900/1800/1900 MHz

- HSxPA Max Power: 1000mA

Antenna connectors: 1

9.5. Expansions

Touch Screen Controller port

9.6. Power and Dimensions

Input power: 9-18 VDC

Power consumption: 20W max.

9.7. Operating environment range

Temperature: -10°C ~ 60°C

Humidity: 5% ~ 95% non-condensing

9.8. Dimensions

Width (mm): 239

Depth (mm): 145

Height (mm): 71

10. PACKAGING

When shipped, the Yacht Router is wrapped in a plastic bag that protects it from humidity. Device is then placed into a cardboard box. A bag containing accessory items is placed inside the box too. List of included accessories is included in the package.


11. INSTALLATION INSTRUCTIONS

Install Yacht Router in a dry indoor space that will meet Operating environment range specifications (chapter 9.7). Follow the installation procedure as specified in this chapter.

11.1. Connect WIFI and mobile network antennas


WARNING: NEVER POWER ON YACHT ROUTER IF WIFI AND MOBILE NETWORK ANTENNAS ARE NOT CONNECTED TO YACHT ROUTER TO AVOID SEVERE DAMAGES ON WIFI AND MOBILE NETWORK MODULES THAT CAN VOID THE WARRANTY.

Connect WIFI antennas as specified on the following picture:




IMPORTANT: Never place both WIFI antennas in the same horizontal level. If you cannot avoid that position minimum horizontal distance between antennas should be 1 meter. If you do not follow that rule, strong interference on both antennas will occur that will highly degrade data traffic, transmitting and receiving performance. NEVER CONNECT BOTH WIFI ANTENNAS DIRECTLY TO YACHT ROUTER. Use WIFI antenna extension cable if it is supplied with your system.

We strongly suggest installation of external WIFI antenna that will increase range and performance in shore-to-ship connectivity (Hotspot in marina). We suggest the same for mobile network antenna too. If you plan to install external antennas use only high-quality antennas and low-loss coax cables to avoid signal degradation (check our [website](http://www.yachtrouter.com)).




11.2. Connect satellite systems (WAN) to Yacht Router

If your boat is equipped with satellite Internet system like Inmarsat, VSAT, Iridium, Globalstar etc., connect it to SAT port as specified on the following picture:




11.3. Connect LAN equipment to Yacht Router

If you plan to connect equipment that will use Ethernet cable connection (computers, IP cameras, IP phones, network printers, media servers etc.) use two LAN ports specified on the following picture:




11.4. Connect Touch Screen Controller or computer that will control Yacht Router

Touch screen controller is a dedicated tablet computer that will give ability to setup Yacht router and easily control wireless networks and Internet connections on your vessel. It is embedded device with the same level of functionality as software that is used on a computer running Windows 7 OS to control Yacht Routers with addition of several features regarding built-in upgrade and software version control functionality. Connect Touch Screen Controller or computer that you plan to use to control Yacht Router to the Controller port as specified on the following picture:



11.5. Connect power supply to Yacht Router Mini

Yacht Router Mini is wide range DC power supply (9-18VDC). We strongly suggest you to install proper fuses on power supply sources cable. Connect power cable as specified on the following picture:



12. SETUP PROCEDURE

Once you finished installation you should proceed to setup procedure as specified in this chapter. If your system is equipped with Touch Screen Controller go to Chapter 9.2. If you system use computer to control Yacht Router system proceed to the following chapter.

12.1. Install Yacht Router Control Software to your computer

Install latest version of Yacht Router Control Software that is supplied with Yacht Router on any computer running Microsoft Windows 7 operating system. YR Control Software is developed for Microsoft Windows 7 operating system but it will probably work on Vista and XP. Anyway, Locomarine does not offer support for any Yacht Router system that is not installed on Windows 7 operating system.

You can download latest version of YR Control Software from [Yacht Router Download web page](#). We suggest you to subscribe to [Software Update Notification Newsletter](#).

As YR Control Software is not hardware demanding application you can use any low power computer based on any Intel Atom or similar processor.

During installation, computer will ask you following question: "Do you want to allow the following program from an unknown publisher to make changes to your computer?". Click on "Yes" and proceed with installation. After installation, check if Yacht Router is connected with Ethernet (CAT5) cable to LAN port on your computer and Controller port on Yacht Router.

12.2. Using Touch Screen Controller with Yacht Router

Check if Touch Screen Controller is connected with Ethernet (CAT5) cable to Yacht Router Controller port. If it is connected power on Touch Screen Controller and wait until YR Control software appears on the screen.

12.3. Power on Yacht Router

Now you can power on Yacht Router. After you turn it on, small power indicator on power button will light up and you should hear few beeps from Yacht Router. After about half a minute of boot period Yacht Router is ready for use.

IMPORTANT: Before starting YR Control Software disconnect your computer from any WIFI or Internet connection. Check that your computer is set to obtain IP address automatically (DHCP enabled). On the following link you can find instructions how to do that: <http://windows.microsoft.com/en-US/windows7/Change-TCP-IP-settings>. If you do not do that, YR Control Software will not be able to connect to Yacht Router.

Now you can start YR Control Software on your computer for the first time.

12.4. Yacht Router initial setup

To enter Yacht Router Setup menu hold  button for 3 seconds.

When you enter **YACHT ROUTER SETUP** menu click on Unlock Password button and enter password. This password will protect your Yacht Router system from unauthorized access.

IMPORTANT: It is very important to set Unlock Password. If you do not set this password anybody can access your Yacht Router system by simple installation of YR Control Software on any computer connected to the system.

12.5. Satellite Network setup

Once initial setup is finished, you can proceed to Satellite network setup. Press



button for 3 seconds and you

will enter **SATELLITE WAN - Setup** menu. This menu consists of:

Satellite WAN Setup

Setup menu consist of the following buttons:

Title

Click on this button to enter friendly name to your satellite network system for easier control. For example, you can name your Inmarsat FleetBroadband connection as "Inmarsat", Ku-Band connection as "VSAT" etc.

Advanced Options

Once you click on this button you will enter Advanced Options menu. This menu consists of the following buttons:

Use DHCP

Click this button to set WAN 1 to use or not to use DHCP. We recommend you to set DHCP to YES and your system will configure automatically. That way you do not have to set any of the following options.

IP

If WAN 1 is set to use DHCP this button will display IP address assigned by satellite router connected to WAN 1 port. If WAN 1 is sent not to use DHCP, click on this button to assign fixed IP address.

Subnet

If WAN 1 is set to use DHCP this button will display Subnet address assigned by satellite router connected to WAN 1 port. If WAN 1 is sent not to use DHCP, click on this button to assign Subnet address.

Gateway

If WAN 1 is set to use DHCP this button will display Gateway address assigned by satellite router connected to WAN 1 port. If WAN 1 is sent not to use DHCP, click on this button to assign Gateway address.

DNS 1

If WAN 1 is set to use DHCP this button will display DNS 1 address assigned by satellite router connected to WAN 1 port. If WAN 1 is sent not to use DHCP, click on this button to assign DNS 1 address.

DNS 2

If WAN 1 is set to use DHCP this button will display DNS 2 address assigned by satellite router connected to WAN 1 port. If WAN 1 is sent not to use DHCP, click on this button to assign DNS 2 address.

Vessel Network Access Restrictions

Under this menu you can restrict selected vessel networks to access Internet via WAN 1 source. For example, you can restrict all users connected to Guest WIFI vessel network to access Internet via VSAT to avoid high volume traffic and unexpected costs.

12.6. Mobile Network setup

From main Yacht Router screen press



button for 3 seconds and you will enter **MOBILE NETWORK** setup menu. This menu consists of:

SIM Card PIN

Click on this button to enter SIM Card PIN in necessary.

IMPORTANT: We recommend you to disable PIN code on your SIM card because if you insert another SIM card Yacht Router will not be able to connect to the mobile network. In the same time, you have to be know that unprotected SIM card (without PIN code) can be used on another devices (phones, tablets, etc) if it is stolen.

Enable Roaming

Click on this button if you want to enable or disable roaming. If you disable roaming, Yacht Router will not access Internet once you are SIM card is in roaming to avoid unexpected costs.

APN

Click on this button to enter APN (Access Point Name) of your Internet Mobile provider. Usually this is the only data you need to enter to connect to the Internet via mobile network. You can obtain APN from your mobile network provider.

Advanced Option

Once you click on this button you will enter MOBILE NETWORK - Advanced Options menu. This menu consists of the following buttons:

Phone Number

Some mobile network providers insist on phone number entry. Contact your provider for more details.

Username

Some mobile network providers insist on username entry. Contact your provider for more details.

Password

Some mobile network providers insist on password entry. Contact your provider for more details.

SIM Card PUK

Use this button to enter SIM card PUK number to unlock your SIM card. SIM card will lock if you enter wrong SIM card PIN three times.

Modem Init

This option is very rarely used. Do not change this parameter if you are not sure what you are doing. Default parameter is without any entry. Before your modem software dials a phone number, it initializes (inits) the modem by sending it a series (string) of commands, typically Hayes commands. These commands configure the modem's options for things like error correction, data compression, flow control, and many other parameters. The important thing about modem init strings is that having the right one often makes the difference between connecting and not.

Dial Command

This option is very rarely used. Do not change this parameter if you are not sure what you are doing. Default parameter is ATDT. The command set consists of a series of short text strings which combine together to produce complete commands for operations such as dialing, hanging up, and changing the parameters of the connection.

Vessel Network Access Restrictions

Under this menu you can restrict selected vessel networks to access Internet via Mobile Network. For example, you can restrict all users connected to Guest WIFI vessel network to access Internet via Mobile Network to avoid high volume traffic and unexpected costs.

12.7. WIFI Network setup

From main Yacht Router screen press



button for 3 seconds and you will enter **WIFI NETWORK** setup menu.

This menu consists of:

Select WIFI Network

Click on this button to choose a WIFI network that you want to connect to.

Password

Click on this button to enter a password if WIFI network that you want to connect to require it.

Advanced Options

Once you click on this button you will enter WAN 1 - Advanced Options menu (where WAN 1 will be friendly name of you network that you entered under Title menu. This menu consists of the following buttons:

Use DHCP

Click this button to set WAN 1 to use or not to use DHCP. We recommend you to set DHCP to YES and your system will configure automatically. That way you do not have to set any of the following options.

IP

If WAN 1 is set to use DHCP this button will display IP address assigned by satellite router connected to WAN 1 port. If WAN 1 is sent not to use DHCP, click on this button to assign fixed IP address.

Subnet

If WAN 1 is set to use DHCP this button will display Subnet address assigned by satellite router connected to WAN 1 port. If WAN 1 is sent not to use DHCP, click on this button to assign Subnet address.

Gateway

If WAN 1 is set to use DHCP this button will display Gateway address assigned by satellite router connected to WAN 1 port. If WAN 1 is sent not to use DHCP, click on this button to assign Gateway address.

DNS 1

If WAN 1 is set to use DHCP this button will display DNS 1 address assigned by satellite router connected to WAN 1 port. If WAN 1 is sent not to use DHCP, click on this button to assign DNS 1 address.

DNS 2

If WAN 1 is set to use DHCP this button will display DNS 2 address assigned by satellite router connected to WAN 1 port. If WAN 1 is sent not to use DHCP, click on this button to assign DNS 2 address.

Vessel Network Access Restrictions

Under this menu you can restrict selected vessel networks to access Internet via WIFI connection. For example, you can restrict all users connected to Guest WIFI vessel network to access Internet via WIFI network to avoid high volume traffic and unexpected costs.


12.8. Vessel LAN network setup

There is no any setup on Vessel LAN network. All you can do is to enable or disable it.

12.9. Vessel WIFI 1 network setup

VESSEL WIFI 1 network is designed to be used by yacht owner, but it is up to you to decide how you are going to name it or use it.

From main Yacht Router screen press



button for 3 seconds and you will enter **VESSEL WIFI 1** network setup menu. This menu consists of:

WIFI name (SSID)

Click on this button to enter friendly name to your VESSEL WIFI 1 network. For example, if you plan that this network will be used by owner you can name it *"Yacht name – Owner"*.

Password


Click this button to enter password that will be used by users to connect to VESSEL WIFI 1 network (minimum 8 characters).

IMPORTANT: It is very important to set this password. If you do not set this password everybody will be able connect to VESSEL WIFI 1 network and surf the Internet that could lead to unexpected costs.

12.10. Vessel WIFI 2 network setup

VESSEL WIFI 2 network is designed to be used by guests or crew, but it is up to you to decide how you are going to name it or use it.

From main Yacht Router screen press



button for 3 seconds and you will enter **VESSEL WIFI 2** network setup manu. This menu consists of:

WIFI name (SSID)

Click on this button to enter friendly name to your VESSEL WIFI 2 network. For example, you can name it *"Yacht name - Guest"*.

Password

Click this button to enter password that will be used by users to connect to VESSEL WIFI 2 network (minimum 8 characters).


IMPORTANT: It is very important to set this password. If you do not set this password everybody will be able connect to VESSEL WIFI 2 network and surf the Internet that could lead to unexpected costs.

13. HOT TO USE YACHT ROUTER CONTROL SOFTWARE

Yacht Router is very easy to use and after initial setup it is ready to be used. In a next few chapters we will explain how to so it.

13.1. Main Screen

On the following picture you can find explanation of all main screen elements:



13.2. How to enable and disable vessels networks

If you want to enable or disable VESSEL LAN and WIFI networks you can do it with single click on a button. For example, if you click on VESSEL WIFI 2 button you will see "Please Wait..." message and after short period status border around button will light green and network will be enabled. If you click it again you will see "Please Wait..." message again and after short period status border around button will light gray and network will be disabled.

13.3. Hot to switch Internet sources

If you want to switch from one Internet source to another all you have to do is to click on one of the button in upper row. For example, if Yacht Router is currently connected to SATELLITE NETWORK, first button in upper row will light yellow. If you want to switch to MOBILE NETWORK Internet source click on MOBILE NETWORK button. You will see "Please Wait..." message and after short period status border around button will light yellow and Yacht Router will connect all VESSEL NETWORKS (LAN, WIFI 1 and WIFI 2) to the Internet via MOBILE NETWORK. At the same time, SATELLITE NETWORK status border around button will light gray as an indication it is inactive.

13.4. How to use Yacht Router Remote Support

If you have a problem with your Yacht Router system you can use Remote Support feature. Remote Support gives you ability to connect your Yacht Router to our main server. Once you connect it, you should contact our support service by [phone](#) or [e-mail](#) to explain what kind of support you need. To use Remote Support you MUST connect your Yacht Router to the Internet.

To request Remote Support click on  button for 3 seconds to enter **YACHT ROUTER SETUP** menu.

Once you enter Setup menu click on **Request Remote Support** button, confirm with **YES** button and click on  button.

Once you confirm, you will enter Yacht Router Support Network screen. You will notice list of small green sentences. If the last one is CONNECTED you are connected to our server and you can contact our support team.

Once you receive notification from our support team (by mail, SMS or phone), you can disconnect from Yacht Router main server with click on  button.

13.5. How to lock Yacht Router

If you want to lock Yacht Router to prevent other people use it press  button for 3 seconds. You will exit main control page and Locomarine Screen Saver will appear.

If you click anywhere on the screen you will be prompted to enter Unlock Password. If you do not know how to setup Unlock Password check chapter “13.4. Yacht Router initial setup” on page 10.

IMPORTANT: It is very important to set Unlock Password. If you do not set this password anybody can access your Yacht Router system by simple installation of YR Control Software on any computer connected to the system.

If you did not set Unlock Password, once you click on Locomarine Screen Saver you will not be prompted to enter Unlock Password.

14. LOCOMARINE LIMITED FACTORY WARRANTY

Locomarine manufactures marine electronic products which are marketed and supported worldwide via the Locomarine distributor, dealer and partner network. Each and every Locomarine distributor, dealer and partner is committed to service and support the products in accordance with the market's needs and requirements. In addition, the Locomarine distributor, dealer and partner networks are obliged to service and support the products irrespective of who sold and installed the product.

Locomarine Limited Factory Warranty for Yacht Router products can be downloaded from [Yacht Router Download web page](#).

15. FCC INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

16. DECLARATION OF CONFORMITY

Hereby, Locomarine d.o.o. declares that this Yacht Router device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

17. INDUSTRY CANADA NOTICE TO USERS

Locomarine d.o.o. cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation of the device.